



download "ruwido schutzengel" information portal

NFC: first activate NFC on your smartphone. then hold the backside of the schutzengel close to the backside of your smartphone (next to NFC antenna). once the schutzengel is recognized, the "ruwido schutzengel" page can be opened in the App Store / Google Play Store and the app is available for download.

QR code: scan the QR code on the backside of the schutzengel with your smartphone. once the code is recognized, the "ruwido schutzengel" page can be opened in the App Store / Google Play Store and the app is available for download.

manually: open the App Store / Google Play Store on your smartphone. search for the "ruwido schutzengel" app and load it down.

user manual

before using the device, please carefully read following instructions. further information can be found at: www.schutzengel.ruwido.com/user-instructions

schutzengel first time activation

connect the schutzengel to a power source using the supplied cable. if possible, charge fully (flashing green). the schutzengel is activated as soon as removed from the power source. check your contacts via the "ruwido schutzengel" information portal. download the portal from the app store / google play store.

for further information visit our website.



www.schutzengel.ruwido.com
schutzengel@ruwido.com



designed, developed & manufactured in austria

check your contacts / report infection


for this, the "ruwido schutzengel" information portal app must be installed on the smartphone – see section download "ruwido schutzengel" information portal.


NFC: first activate NFC on your smartphone. then hold the backside of the schutzengel close to the backside of your smartphone (next to NFC antenna). once the schutzengel is recognized, the "ruwido schutzengel" information portal opens up. follow the instructions in the portal.


QR code: scan the QR code on the backside of the schutzengel with your smartphone. once the code is recognized the "ruwido schutzengel" information portal opens. follow the instructions in the portal.

manually: open the "ruwido schutzengel" information portal on your smartphone. position the schutzengel close to your smartphone. follow the instructions in the portal.

activate schutzengel / switch mode

 **switch on / to "active" mode:**
key press > 3 seconds, signalized through 1 beep tone and a green light.


 **switch to "silent" mode:**
key press > 3 seconds, signalized through 2 beep tones and a yellow light.


 **turn off / deactivate schutzengel:**
key press > 3 seconds, signalized through 3 beep tones and a red light.


battery status

a short press on the schutzengel button shows the battery status and whether the device is activated:


 **green light:**
battery status good, device active.


 **yellow light:**
battery charging recommended, device active.

 **red light:**
battery charging required, device active.

 **no light response:**
battery empty or device not active / switched on.


"active" and "silent" mode


 **"active" mode:**
contact-tracing active. the schutzengel signalizes through red light and vibration a distance below approx. 2 meters.

 **"silent" mode:**
contact-tracing active, but no acoustic/optic signal if distance is not kept.

battery charging status


indicates charging status when plugged in for charging:

 **flashing green:**
battery fully charged, no more charging necessary.


 **flashing yellow:**
battery not fully charged, device is charging.

 **flashing red:**
battery very low, device is charging.

legal notices as well as information concerning security and disposal

 **declaration of conformity**
hereby, ruwido austria gmbh declares that the radio equipment type model: 851A is in compliance with directive 2014/53 /EU. the full text of the EU declaration of conformity is available at the following internet address:
www.schutzengel.ruwido.com/user-instructions

safety instructions and information on proper disposal are to be found at:
www.schutzengel.ruwido.com/user-instructions

 removing the rechargeable battery from the device is not permitted. the shown **WEEE mark** means that this device and the battery installed are in accordance with applicable laws and must be disposed separately from normal household waste. for proper treatment, recovery and recycling, take this product(s) to designated collection points. (please contact your local authority for further details of your nearest designated collection point.)

RF exposure and information on frequency bands and power:
the schutzengel has been tested and complies with the applicable regulatory requirements for radio frequency radiation (RF). maximum transmission power of the radio frequency: 2,400 – 2,483.5 MHz, less than 5 mW EIRP

ruwido

ruwido austria gmbh
koestendorfer str. 8 . 5202 neumarkt . austria . schutzengel@ruwido.com